

Compatibilidade

- Windows
- Mac OS X
- Mobile devices

Instruções de Segurança

• DANOS DE AUDIÇÃO

Altos níveis de volume áudio poderão causar danos de audição. Deverá evitar longa exposição a volumes áudio demasiado elevados.

Ajustar o Microfone

O braço do microfone poderá ser ajustado verticalmente. Posicione o microfone de forma a que esteja a mais de 2cm de distância da boca. Certifique-se que os lábios não tocam no microfone.

Resolução de Problemas

• NÃO OUÇO NADA

Certifique-se que o headset se encontra ligado.

Certifique-se que o nível de volume áudio no seu computador ou dispositivo móvel não se encontra no mínimo ou em modo mudo.

Certifique-se que o sistema operativo registou o headset como o dispositivo áudio pré-definido.

• NINGUÉM ME OUVI

Ajuste o volume do microfone no painel de controlo do sistema operativo e/ou verifique as configurações áudio no seu software de comunicação.

• A MINHA VOZ APRESENTA DISTORÇÃO

Aumente a distância entre o microfone e a boca. Quanto mais próximo o microfone se encontrar da boca, maior é a probabilidade da sua voz ser distorcida.



HS: *cyber*

STEREO GAMING HEADSET

User Guide
Guia de Utilizador

Compatibility

- Windows
- Mac OS X
- Mobile devices

Safety Instructions

• DAMAGE TO HEARING

High volume levels may cause damage to hearing.
Avoid listening to audio at very high volumes, especially during extended periods of time.

Adjusting the Microphone

The microphone arm can be pivoted up and down.
Position the microphone so that it is at least 2cm away from your mouth. Make sure that your lips don't touch the microphone.

Troubleshooting

• I CAN'T HEAR ANYTHING

Make sure that the headset is plugged in.

Make sure that the volume level in your computer or mobile device is not muted or set to minimum.

Check if your operating system has registered the headset as the default audio device.

• OTHER PEOPLE CAN'T HEAR ME

Adjust the microphone volume on the OS control panel and check the audio settings in your messaging program.

• MY VOICE SOUNDS DISTORTED

Increase the distance between the microphone and your mouth. The closer the microphone is to your mouth, higher is the probability that your voice will sound distorted.

www.1-Life.eu

One Life. **Play it hard.**