


1life

hd:lightspeed²

hdd enclosure caixa externa para disco rígido



Windows



Mac OS

USB
3.0

1life

hd:lightspeed²

**USB
3.0**

USER'S GUIDE

SPECIFICATONS

- **HDD Support:**
SATA 2.5"
- **Material:**
Aluminium and plastics
- **Input connections:**
SATA HDD
- **Output connections:**
USB 3.0 (up to 5.0Gbps)
compatible with other USB versions
- **Dimensions:**
130 x 85 x 12 mm
- **Power supply:**
USB
- **Package contents:**
1ife hd:lightspeed², USB cable,
User Manual
- **System requirements:**
USB 2.0 port;
Windows 2000/XP/Vista/7;
Mac OS X (10.3.0 or higher)
- **Warranty:**
2 years

1.0 HARDWARE SETUP

- Make sure that your SATA 2.5" drive has the jumper set in "Master" mode.
- Insert the drive into the enclosure.
- Connect the USB cable to the enclosure and then to your computer.
- The computer should now detect the new drive.

2.0 FORMAT YOUR HARD DRIVE

(Windows)

(If the drive already appears in "My Computer", please skip to 2.2)

2.1

For an un-partitioned or un-formatted new drive, it normally does not automatically appear in "My Computer" in the first time.

Please follow these steps:

Windows 2000/XP/VISTA/7

- Right click on "My Computer" and choose "Manage" from the drop-down list. A window titled "Computer Management" will pop up.
- Click on the "Disk Management". All connected disk drives will be displayed in the lower right-hand corner of the window. Carefully locate your new external drive, right click on it to initialize your drive, create or delete new partitions, and/or format an existing partition.

2.2

Go to "My Computer", locate the removable disk, right click on it, and select "Format" from the drop-down list, follow the instructions to complete the formatting process.

Note:

Using this method to format your drive will result in a single partition in the

largest drive capacity, which is also highly recommended.

Note:

For Windows 2000/XP/VISTA/7, the default choice is NTFS. However, you can also choose to format the drive with FAT32 ONLY IF the drive size is smaller or equal to 32GB.

3.0 FORMAT YOUR HARD DRIVE (Mac OS X)

In Mac OS X open a new Finder window and navigate to applications. In the folder "Utilities" you can find the application "Disk Utility", open it. Select the drive in the left column and navigate through right side options for partition and formatting. Use the recommended format if you want to use your drive only with Mac, or use NTFS if you want to share contents between Mac OS X and Windows based computers.

FAQs

Q: I can't find the drive under my computer, why?

A: Please make sure your drive is set to "Master", also check section 2.0 to initialize your drive.

GUIA DO UTILIZADOR

ESPECIFICAÇÕES

- **Suporte de discos:**
SATA 2.5"
- **Material:**
Alumínio e plástico
- **Ligações de entrada:**
SATA HDD
- **Ligações de saída:**
USB 3.0 (até 5.0Gbps);
compatível com outras versões USB
- **Dimensions:**
130 x 85 x 12 mm
- **Fonte de alimentação:**
USB
- **Conteúdo da embalagem:**
1ife hd:lightspeed², cabo USB,
Manual de Utilizador
- **Requisitos de sistema:**
porta USB 2.0
Windows 2000/XP/Vista/7;
Mac OS X (10.3.0 ou superior)
- **Garantia:**
2 anos

1.0 CONFIGURAÇÃO DE HARDWARE

- Certifique-se que o seu disco SATA 2.5" tem o jumper em modo "Master"
- Insira o seu disco na caixa externa.
- Conecte o cabo USB na caixa externa e depois no seu computador.
- O seu computador deverá agora detectar o disco.

2.0 FORMATAÇÃO DO DISCO (Windows)

(Se o seu disco aparece no "O Meu Computador", passe para o item 2.2)

2.1

Um disco não formatado ou não particionado, normalmente não aparece automaticamente em "O Meu Computador".

Por favor, siga estes passos:

Windows 2000/XP/VISTA/7

- Clique com o botão direito do rato sobre "O Meu Computador" e seleccione "Gerir". Irá surgir uma janela intitulada "Gestão de Computadores".
- Clique em "Gestão de Discos". Todos os discos conectados serão exibidos na janela. Localize o seu disco externo, clique com botão direito do rato de forma a iniciar o disco, criar, eliminar ou formatar partições existentes.

2.2

Aceda a "O Meu Computador", localize o disco removível, faça clique com o botão direito do rato e seleccione formatar, siga as instruções de forma a completar o processo de formatação.

Nota:

Ao formatar o seu disco desta forma, irá resultar numa única partição com a

capacidade máxima do seu disco, o que é recomendado.

Nota:

Para o Windows 2000/XP/VISTA/7, por predefinição, a formatação é feita no sistema de ficheiros NTFS. No entanto, poderá formatar o seu disco em sistema de ficheiros FAT32, se este tiver uma capacidade igual ou inferior a 32GB.

3.0 FORMATAÇÃO DO DISCO (Mac OS X)

No Mac OS X abra uma nova janela do Finder e navegue para as aplicações. Na pasta "Utilitários" encontra-se a aplicação "Utilitário de Disco", abra-a. Seleccione o seu disco na coluna da esquerda e navegue pelas opções no lado direito para fazer partições e formatar. Use o formato recomendado pelo programa para usar apenas com Mac, ou formate em NTFS para usar com computadores Mac e Windows.

PERGUNTAS FREQUENTES

P: Não consigo localizar o disco no meu computador, porquê?

R: Certifique-se que o seu disco se encontra em modo "Master", verifique o item 2.0 deste manual.

www.1ife.eu

A graphic consisting of several overlapping, wavy, horizontal bands of varying shades of teal and light blue, creating a sense of motion and depth. The bands are set against a dark teal background.

1ife
Simplify it.