

Requisitos de Sistema

- Windows XP / Vista / 7 / 8 / 8.1
- Software áudio
- Porta USB disponível

Instruções de Segurança

- **INTERFERÊNCIAS RÁDIO**
O dispositivo poderá ser afetado por campos estáticos, elétricos ou de alta frequência (instalações rádio, telefones, descargas de micro-ondas). Em caso de ocorrência, aumente a distância para o dispositivo causador de interferência.
- **DANOS DE AUDIÇÃO**
Altos níveis de volume áudio poderão causar danos de audição. Deverá evitar longa exposição a volumes áudio demasiado elevados.

Conectar o Dispositivo

- Conecte o headset a uma porta USB no seu computador.
- Não conecte o headset a um hub USB.
- Não é necessária a instalação de controlador para o funcionamento do dispositivo. No entanto, se pretender

- ativar o áudio virtual 7.1 Surround Sound, ou ajustar cada canal individualmente, será necessária a instalação do software.
- Descarregue o software na página do produto em 1-Life.eu. Descompacte a pasta, localize e faça duplo clique sobre o ícone "Setup". Siga as instruções apresentadas.


NOTA:
De forma a poder instalar o software, o dispositivo necessita de estar ligado ao computador.

- Após conclusão da instalação, poderá encontrar o ícone do software no canto inferior direito da barra de tarefas do sistema operativo. Faça duplo clique sobre o mesmo de forma a abrir o software.
- De forma a ativar o áudio virtual 7.1 Surround Sound, deverá fazer clique sobre o seguinte botão:



Faça novamente clique sobre o botão para desativar o efeito áudio.

- Poderá ajustar as suas preferência para cada canal áudio no seguinte menu:



Ajustar o Microfone

O braço do microfone poderá ser ajustado verticalmente. Posicione o microfone de forma a que esteja a mais de 2cm de distância da boca. Certifique-se que os lábios não tocam no microfone.

Resolução de Problemas

- **NÃO OUÇO NADA**
Certifique-se que o nível de volume áudio no controlador não está definido no mínimo e que o headset se encontra ligado ao computador.
Certifique-se que o sistema operativo registou o headset como o dispositivo áudio pré-definido.
- **NINGUÉM ME OUVE**
Ajuste o volume do microfone no painel de controlo do sistema operativo e/ou verifique as configurações áudio no seu software de comunicação.
- **A MINHA VOZ APRESENTA DISTORÇÃO**
Aumente a distância entre o microfone e a boca. Quanto mais próximo o microfone se encontrar da boca, maior é a probabilidade da sua voz ser distorcida.
- **O HEADSET NÃO REPRODUZ SURROUND SOUND**
Verifique se o software de leitor média, os ficheiros média ou o jogo que está a utilizar no computador suportam Surround Sound e, se necessário, ajuste as definições áudio.



SURROUND SOUND GAMING HEADSET



System Requirements

- Windows XP / Vista / 7 / 8 / 8.1
- Audio software
- Available USB port

Safety Instructions

- **RADIO INTERFERENCE**
The device may be affected by strong static, electrical or high-frequency fields (radio installations, mobile phones, microwave discharges). If this occurs, increase the distance between the device that is causing interference.
- **DAMAGE TO HEARING**
High volume levels may cause damage to hearing. Avoid listening to audio at very high volumes, especially during extended periods of time.

Connecting the Device

- Connect the headset to an USB port in your computer.
- Do not connect the headset into an USB hub.
- No driver installation is required to operate the device. However, if you want to activate the 7.1 virtual Surround

- Sound effect, or adjust each channel individually, you will need to install the software.
- Download the software from the product page at 1-Life.eu. Unpack the folder, locate and double click the Setup icon. Follow the on-screen instructions.


NOTE:
In order to install the software, the headset needs to be connected to the computer.

- After the installation is complete, you may find the software icon at the bottom right corner of the OS task bar. Double click it in order to open the software.
- To activate the 7.1 virtual Surround Sound effect press the following button:



Press the button again in order to deactivate the effect.

- You can adjust your preferences for each sound channel in the following menu:



Adjusting the Microphone

The microphone arm can be pivoted up and down. Position the microphone so that it is at least 2cm away from your mouth. Make sure that your lips don't touch the microphone.

Troubleshooting

- **I CAN'T HEAR ANYTHING**
Make sure that the volume level on the in-line controller is not set to minimum and that the headset is plugged in. Make sure that the volume level in Windows is not muted or set to minimum. Check if your operating system has registered the headset as the default audio device.
- **OTHER PEOPLE CAN'T HEAR ME**
Adjust the microphone volume on the OS control panel and check the audio settings in your messaging program.
- **MY VOICE SOUNDS DISTORTED**
Increase the distance between the microphone and your mouth. The closer the microphone is to your mouth, higher is the probability that your voice will sound distorted.
- **THE HEADSET DOESN'T REPRODUCE SURROUND SOUND**
Check if the media player, media files or game that you're using on your computer support surround sound and, if necessary, adjust the sound settings.